



The Kerry Company MPO-1Q manual pump is for those applications that require the ability to manually stroke the actuator. The manual pump is supplied with two hose assemblies and quick disconnects, checked hose ends. To manually stroke the Kerry Actuator, simply attach the hose ends to the pressure test taps supplied standard on all Kerry Actuators. Position the handle of the four way directional control valve for the direction of travel and stroke the pump.

****CAUTION:** Please note the position of the rod prior to use of the manual pump. Before terminating the use of the manual pump return the rod in the original position. This will prevent the overflowing of the actuator. Overflowing the actuator will cause damage.

****CAUTION:** Electrical power to the actuator motor must be disconnected before using the manual pump. Failure to do so may cause damage to the manual pumping unit or operator.